




Trigger Shifter (Push-Pull)


### Shifting Lever

For the best results, please follow instructions in this leaflet. Contact your local bike shop if any problems are experienced with the product.


- 1** 1. Put the shifter into the handlebar.  
2. Set to a proper position and tighten the clamp bolt to 5-7 Nm with a 5mm Allen key.




- 2** Front Derailleur / Left Shifter  
Turn the cable adjuster to adjust the shifting stroke of the front derailleur.





- 3** Rear Derailleur / Right Shifter  
Shift the rear derailleur from the highest gear (the smallest sprocket) to the next gear (the second sprocket, to the left of the smallest sprocket)  
a. If the chain does NOT shift to the second sprocket, turn the cable adjuster direction A.  
b. If the chain shifts to the second sprocket but rubs the third sprocket (to the left of the second sprocket), turn the cable adjuster direction B.



# 4 Names of parts



# 5 Front side (left side)



# 6 Front side (left side)

